


Maintenance

During daily use, please do not wear the band too tightly around your wrist and keep its contact area dry. You should also clean the wristband regularly with water. Please stop using the product immediately and seek medical assistance if the contact area on your skin begins to show signs of redness or swelling.

Mi Smart
Band 3/4
Strap


Installing the Fitness Tracker
Removing the Fitness Tracker
Maintenance

Installing the Fitness Tracker



1. Insert one end of the fitness tracker into the slot from the front of the wristband.
2. Press down on the other end with your thumb to push the fitness tracker into the slot completely.

Removing the Fitness Tracker



Remove the wristband from your wrist, hold on to each end and pull on the wristband until you see a small gap between the fitness tracker and the wristband. Use your finger to pop the fitness tracker out of its slot from the front side of the wristband.